


If you have a Sky box:



When a Sky box is installed, connect RF OUT 2 to RET on faceplate.

Connect AERIAL IN on Sky Box to TV on faceplate. This gives TV (Freeview) and Sky to the bedroom.

NB. The link (fly) cables from the satellite box to the TV and RET sockets are not provided.

Please note standard fly cables will have male connectors both ends and an additional male/female adaptor may also be required to complete the connection.

If you have no Sky box:

Connect SAT2 with the f-type connection on the link cable to the RET coaxial socket to send TV/Radio signals to either a bedroom point in single bed dwelling or to a local amplifier which will then feed two or more points.

NB. Connecting SAT1 via link cable will give satellite only in the bedroom. Use SAT2 to give both satellite and terrestrial.